

Property Library for Carbonyl Sulfide

LibCOS

Prof. Hans-Joachim Kretzschmar
Dr. Sebastian Herrmann
Dr. Matthias Kunick
Ines Jaehne
Tobias Goepfert

Property Functions

Functional Dependence	Function Name	Call from Fortran Program	Property or Function	Unit of the Result
$c_p = f(p, t, x)$	cp_ptx_COS	CP_PTX_COS(P,T,X)	Specific isobaric heat capacity	kJ/(kg K)
$c_v = f(p, t, x)$	cv_ptx_COS	CV_PTX_COS(P,T,X)	Specific isochoric heat capacity	kJ/(kg K)
$h = f(p, t, x)$	h_ptx_COS	H_PTX_COS(P,T,X)	Specific enthalpy	kJ/kg
$\kappa = f(p, t, x)$	ka_ptx_COS	KA_PTX_COS(P,T,X)	Isentropic exponent	-
$p_s = f(t)$	ps_t_COS	PS_T_COS(T)	Vapor pressure from temperature	bar
$\rho = f(p, t, x)$	rho_ptx_COS	RHO_PTX_COS(P,T,X)	Density	kg/m ³
$s = f(p, t, x)$	s_ptx_COS	S_PTX_COS(P,T,X)	Specific entropy	kJ/(kg K)
$\sigma = f(t)$	sigma_t_COS	SIGMA_T_CO(T)	Surface tension from temperature	N/m
$t = f(p, h)$	t_ph_COS	T_PH_COS(P,H)	Backward function: Temperature from pressure and enthalpy	°C
$t = f(p, s)$	t_ps_COS	T_PS_COS(P,S)	Backward function: Temperature from pressure and entropy	°C
$t_s = f(p)$	ts_p_COS	TS_P_COS(P)	Saturation temperature from pressure	°C
$u = f(p, t, x)$	u_ptx_COS	U_PTX_COS(P,T,X)	Specific internal energy	kJ/kg
$v = f(p, t, x)$	v_ptx_COS	V_PTX_COS(P,T,X)	Specific volume	m ³ /kg
$w = f(p, t, x)$	w_ptx_COS	W_PTX_COS(P,T,X)	Isentropic speed of sound	m/s
$x = f(p, h)$	x_ph_COS	X_PH_COS(P,H)	Backward function: Vapor fraction from pressure and enthalpy	kg/kg
$x = f(p, s)$	x_ps_COS	X_PS_COS(P,S)	Backward function: Vapor fraction from pressure and entropy	kg/kg

Units: t in °C
 p in bar
 x in (kg saturated steam)/(kg wet steam)

Range of validity

Temperature range: from - 138.85 °C to 376.85 °C
Pressure range: from 6.44346×10^{-4} bar to 500 bar

Reference state

$h = 0$ kJ/kg and $s = 0$ kJ/(kg K) at $p = 1,01325$ bar on the saturated liquid line ($x = 0$)

Details on the vapor fraction x

The wet steam region is calculated automatically by the subprograms. For this purpose the following fixed details on the vapor fraction x are to be considered:

Single-phase region

If the state point to be calculated is located in the single-phase region (liquid or superheated steam) $x = -1$ must be entered as a pro-forma value.

Wet-steam region

If the state point to be calculated is located in the wet steam region, a value for x between 0 and 1 ($x = 0$ for saturated liquid, $x = 1$ for saturated steam) must be entered. In this case, the backward functions result in the appropriate value between 0 and 1 for x . When calculating wet steam either the given value for t and $p = -1000$ or the given value for p and $t = -1000$ and in both cases the value for x between 0 and 1 must be entered.

If p and t and x are entered as given values, the program considers p and t to be appropriate to represent the vapor pressure curve. If this is not the case the calculation for the property of the chosen function results in -1 .

Wet steam region: Temperature ranges from $t_{\min} = -138.85$ °C to $t_c = 105.62$ °C
Pressure ranges from $p_{\min} = 6.44346 \times 10^{-4}$ bar to $p_c = 63.6876$ bar

Note:

If the input values are located outside the range of validity, the calculated function will always result in -1000 . Please find more exact details on every function and its corresponding range of validity in the enclosed software documentation in Chapter 3.